

Mesh Basket Strainer

The inside of the strainer baskets are lined with stainless steel mesh instead of the usual filter bags. This avoids the need to dispose the filter bags. On top of that the basket strainer can be cleaned and re-used.

The different micron ratings and sizes (filter surface from 0,05 to 0,3 m²) allow the selection of a suitable basket with regard to the operating conditions (medium, flow rate, ...)

In the RS version, a stainless support layer is welded inside the basket. This protects the filter mesh during backwashing.



Technical data

Material:	Stainless steel 1.4301 (V2A) Stainless steel 1.4401 (V4A)
Micron rating:	5, 20, 25, 50, 100, 150, 200, 250, 300, 400, 500, 800, 1600, 2000, 8000 µm
Accessoires:	Backwashcover

Order information

ASK

		-		-		-	
	Micron rating		Size		Material		Accessoires
	50 50 µm		1 0,15 m ²		V2A		none
	150 150 µm		2 0,30 m ²		F V4A		RS Backwashcover
	400 400 µm		3 0,05 m ²				
	800 800 µm		4 0,1 m ²				

Order example: ASK400-2-F-RS